

Kasutusjuhend

Nutikas RGBIC TV LED-riba 2m

Teil on vaja Nous Smart Home rakendust. Skannige QR-kood või laadige see alla [otselingilt](#)



Kuidas lisada oma seade Nous Smarti rakendusse




1. Ühendage LED-riba ja kontrolleri kokku
2. Ühendage toiteadapter
3. Veenduge, et riba vilgub kiiresti (kui ei, **hoidke toitenuppu all kontrolleri 10 sekundit, kuni see hakkab kiiresti vilkuma, või ühendage lahti ja ühendage toiteadapter 5 korda**)
4. Lülitage oma telefonis sisse Bluetooth ja Asukoht (ajutiselt)
5. Avage rakendus Nous Smart (vajadusel registreeruge rakenduses)
6. Vajutage + ja Lisa seade
7. **Ilmub automaatskaneerimine** ja see soovib teil lisada uue seadme (või saate valida LED-riba kategooria, **vajutada LED-riba ja ühendada see käsitsi**)
8. Kinnitage ühendus ja WiFi-võrgu andmed
9. Alusta sidumist
10. Pärast sidumist saate oma seadme soovi korral ümber nimetada ja see on kasutamiseks valmis


Kuidas ühendada oma seade Alexaga

1. Teie nutitefonis peab olema Alexa rakendus
2. Minge seadetesse ja vajutage "Oskused ja mängud"
3. Otsige Nous Smart Home oskust
4. Luba see
5. Linkige oma Nouse konto Alexaga

6. Paluge Alexal uusi seadmeid avastada




The screenshot shows the Alexa app interface. The top status bar displays the time as 21:28, signal strength, Wi-Fi, and 100% battery. The app header shows a back arrow and the word 'Alexa'. The main menu includes 'Add Device', 'Lists', 'Reminders & Alarms', 'Contacts', 'Routines', 'Things to Try', 'Skills & Games' (highlighted with a red box), 'Activity', 'Help & Feedback', and 'Settings'. The bottom navigation bar shows the home indicator and back arrow.



The screenshot shows the 'Nous Smart Home' skill page in the Alexa app. The top status bar displays the time as 21:28, signal strength, Wi-Fi, and 100% battery. The app header shows a back arrow and the Alexa logo. The skill page includes the 'Nous Smart Home' logo, a rating of 'Rated: Guidance Suggested' with five stars, and a blue 'ENABLE' button (highlighted with a red box). Below the button, it says 'Account linking required'. There is a 'TRY SAYING' section with a dropdown menu set to 'English (US)' and a text input field containing '"Alexa, turn on hallway light"'. Below this is an 'ABOUT THIS SKILL' section. The bottom navigation bar shows the home indicator and back arrow.

3. Enter the Nous Smart APP account and password, then tap "Link Now" to link your Nous Smart account to enable the Skill. Now you can start your smart home journey.




The screenshot shows the login page for the Nous Smart Home skill. It features a 'Logo' placeholder, an 'Account' field with a dropdown menu set to '+1' and a country flag, a 'Password' field with a toggle for visibility, and a red 'Link Now' button (highlighted with a red box). Below the button are links for 'Forgot Password' and 'SMS message'. The bottom navigation bar shows the home indicator and back arrow.

Seadme ühendamine Google Home'iga

1. Teie nutitefonis peab olema rakendus Google Home
2. Avage koduseaded ja klõpsake nuppu "Töötab Google'iga"
3. Otsige üles Nous Smart Home

4. Linkige konto Google Home'iga

5. Kõik rakenduse Nous Smart seadmed kuvatakse pärast sünkroonimist Google Home'is



**Kuidas lahti ühendada ja kustutada
kõik andmed**

